Dale Tiffany, Inc.

ASSEMBLY INSTRUCTIONS:
Item No: TT12061

FOR RETURN SHIPPING PURPOSES:
PLEASE RETAIN ORIGINAL PACKAGING
TO MINIMIZE DAMAGE.

1. Place the base (A) on a level surface.
2. Insert the harp (D) until it sits firmly into the saddle (C).
3. Place the shade (F) over the end of the harp (D).
   and tighten with the finial (G) securing the shade in place.
4. Insert the bulb (E) into the bulb socket (B).



Recommended (1) maximum 40 WATT Type "B" Bulb
Or (1) maximum 13WATT CFL Bulb
(Bulb not included)

Cleaning of your lamp.
Unplug lamp, wipe with a damp cloth.
Do not use abrasives

Listed

Important Safety Instructions

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric stock. This plug will fit in a polarized outlet only one way. If it does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted.

Instrucciones Importantes de Seguridad

Esta Lampara Portatil tiene un enchufe polarizado (una punta es mas ancha que otra), Como una manera de seguridad para reducir el riesgo de una descarga electrica. Este enchufe podra ser conectado a un receptor polarizado de una sola manera si no logra conectar completamente el enchufe, reinviertalo para ponerlo en la posicion correta. Si despues de voltearlo aun no logra conectarlo. favo de contactar con un electricista con licencia (Calificado) nunca utilizar la lampara con una extencion de cordon electrico a menos de que el enchufe de la coneccion es completamente introducida.

*SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

Made in China **Revision – 03/29/12**

Dale Tiffany, Inc.

ASSEMBLY INSTRUCTIONS:
Item No: TT12061

FOR RETURN SHIPPING PURPOSES:
PLEASE RETAIN ORIGINAL PACKAGING
TO MINIMIZE DAMAGE.



1. Ponga la base (A) en una superficie plana.
2. Inserte la arpa (D) hasta que se siente firmemente en la silla de montar (C).
3. Coloque la pantalla (F) sobre el extremo de la arpa (D) y apriete Tuerca Finial (G) aseguranda la pantalla en su lugar.
4. Inserte un bulbo (E) en el zócalo del bulbo (B).

Usar máximo (1) 40 vatios, tipo "B" Bulbo
o máximo (1) bulbo CFL de 13 vatios
(Bulbo no incluido)

Limpieza de lampara.

Desenchufe la lámpara, limpiar con un trapo húmedo.

No utilice los abrasivos.

Listed

Important Safety Instructions

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric stock. This plug will fit in a polarized outlet only one way. If it does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted.

Instrucciones Importantes de Seguridad

Esta Lampara Portatil tiene un enchufe polarizado (una punta es mas ancha que otra), Como una manera de seguridad para reducir el riesgo de una descarga electrica. Este enchufe podra ser conectado a un receptor polarizado de una sola manera si no logra conectar completamente el enchufe, reinviertalo para ponerlo en la posicion correta. Si despues de voltearlo aun no logra conectarlo. favo de contactar con un electricista con licencia (Calificado) nunca utilizar la lampara con una extencion de cordon electrico a menos de que el enchufe de la coneccion es completamente introducida.

*** Guardar estas instrucciones para una referencia futura.**

Hecho en China **Revision – 03/29/12**